




# Odorox<sup>®</sup> Boss XL3<sup>™</sup> Hydroxyl Generator Unit

Owner's Manual



# Table of Contents

SAFETY INFORMATION.....	1
PACKAGE CONTENTS.....	5
OPERATING GUIDELINES.....	6
OPERATING INSTRUCTIONS.....	7
CARE INSTRUCTIONS.....	8
OPTIC REPLACEMENT INSTRUCTIONS.....	9
TROUBLESHOOTING GUIDE.....	10
SPECIFICATIONS, REPLACEMENT PARTS & LIMITED WARRANTY.....	11
LIMITED USE END-USER LICENSE AGREEMENT.....	14



## Safety Information

# Warning!

Use this hydroxyl generator only for its intended purpose as described in this Owner's Manual.

**PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.**

**IMPORTANT SAFEGUARDS**

When using this system, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this hydroxyl generator.
- To avoid fire or shock hazard, plug the equipment directly into a grounded AC electrical outlet.
- Remove all packaging material before use.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiators, stoves, or heaters.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. DO NOT use near water.
- **WARNING!**: Always unplug the generator before moving it, cleaning, or whenever the generator is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT operate any generator with a damaged cord or plug, if motor fan fails to rotate, after the generator malfunctions, or if it has been dropped or damaged in any manner. Return generator to manufacturer or authorized repair facility for examination, electrical or mechanical adjustment, or repair.
- Use generator only for intended use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended may cause hazards.
- **INDOOR USE ONLY!**

# Safety Information

- NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the Air Intake Opening/Grill.
- Keep unit away from heated surfaces and open flames.
- CAUTION!: for general ventilating use only. DO NOT use to exhaust hazardous or explosive materials and vapors.
- DO NOT attempt to repair or adjust any electrical or mechanical components on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by authorized personnel only.
- DO NOT plug the cord in with wet hands: electric shock could result.
- NEVER use detergents, gasoline, furniture polish, paint thinner or other household solvents to clean any part of the generator.
- DO NOT under any circumstances cut or remove the third (Ground) prong from power cord. For personal safety, this generator must be properly grounded.



# Safe Handling and Disposing of Mercury

Mercury is used in the Boss XL3™ device in order to generate the plasma needed to produce UV-C radiation. This is similar to the use of mercury in many types of commercial, fluorescent light fixtures. As long as the glass or quartz outer bulb is intact, mercury is contained within the fixture and poses no health hazard. In the event that an optic breaks, less than 25 mg of mercury could be released. This is much less than what is present in a commercial thermometer. Liquid metallic mercury is hazardous due to its potential to release mercury vapor. In humans, approximately 80% of inhaled mercury vapor is absorbed via the respiratory tract, where it enters the circulatory system and is distributed throughout the body. Short term exposure to 25 mg of spilled mercury does not pose a health hazard, **provided that the source of the mercury is removed promptly**. Chronic exposure by inhalation, even at low concentrations in the range 0.7–42 µg/m<sup>3</sup>, can cause effects such as tremors, impaired cognitive skills, and sleep disturbance in workers. The OSHA limit for occupational exposure of elemental mercury is 0.1 mg/m<sup>3</sup>. Mercury is also used in most fluorescent light fixtures.

In the event that the device optic light does not function, the optics should be checked to ensure that they are intact. If the optic is cracked, but not broken, it should be replaced. Cracked optics should be double sealed in plastic bags and disposed of according to local, approved procedures. In the event that the optic breaks and the mercury is spilled, clean-up should be done immediately according to the following procedure published by the Environment Protection Agency.

- Evacuate the room for at least 15 minutes.
- DO NOT attempt to clean up the spill with a vacuum cleaner, mop or broom.
- Dispose of clothing, fabric etc. that has come in contact with mercury; DO NOT wash.
- Only the individual to clean up the spill should re-occupy the space.
- Close the doors to the area of the spill and turn off the HVAC system; open exterior windows and direct room air out of the window with fans or use an exhaust fan if the area is equipped with one that vents directly outdoors.
- Cover shoes with disposable foot covers or wear shoes that will be disposed of.
- Remove jewelry as mercury will amalgamate with metals and ruin them.
- Use a commercial mercury spill clean-up kit to remove the spilled mercury. (See list of suppliers on the next page).
- **Identify items in the spill area that can be cleaned and those that cannot.** Non-porous surfaces (finished wood, plastic or concrete) can be cleaned following this guidance. Porous surfaces or fabric-covered items (upholstery, carpeting, stuffed animals, pillows, backpacks, unfinished wood, cork, cardboard) are difficult to clean because mercury beads may be trapped in these materials. If you decide you cannot clean these items, place them in plastic trash bags or cover or wrap them in a double layer of plastic and carefully seal with tape. Place the wrapped items in a secure place, preferably outdoors and out of the reach of children and pets. You should consult with a trained professional about how to decontaminate or dispose of these items safely.
- **Wear gloves to carefully pick up the larger pieces of broken glass and what remains of the broken device and place them on a paper towel.** Gently fold the paper towel around these pieces so you can pick the bundle up and place it in a zipper-type plastic bag. **Use index cards or stiff cardboard to push smaller pieces of glass and mercury beads together into a pile.** Shine a flashlight at an angle to locate beads of mercury. The beads will reflect light from the flashlight. Check for mercury in cracks or in hard-to-reach areas where beads may be hidden or trapped. Check a wide area beyond the spill.

- **Use the eyedropper to collect mercury beads and place them in the plastic bag.** Hold the eyedropper at an angle to draw the mercury into the tip. Keep the eyedropper at an angle to stop the mercury from rolling back out until you can put the mercury into the plastic bag. Wrap tape (sticky side out) around your gloved fingers and carefully use it to pick up any remaining glass or beads. Check again with the flashlight to be sure that no beads of mercury remain.
- At this point, mercury beads may still be trapped in cracks or crevices on irregular surfaces. **Sprinkle sulfur powder over the contaminated area** and rub it gently all over the surface and into the cracks with a paper towel. Sulfur powder binds with mercury. Use a paper towel dampened with water followed by wiping with another damp paper towel to clean up the sulfur and mercury. Place the used paper towels in a zipper-type plastic bag.
- **Put all the items that were used to pick up the mercury, including index cards or cardboard, eyedropper, contaminated tape, paper towels, and zipper-type bags into the trash bag.** Carefully remove rubber gloves by grabbing them at the wrist and pulling them inside out as they come off. Place the used gloves in the trash bag.
- **Carefully seal the trash bag that contains the mercury-contaminated waste** and put it in a secure place, preferably outdoors and out of reach of children and pets until it can be disposed of safely.
- If possible, **open a window and use a fan to ventilate the area to the outdoors for 24-48 hours** before resuming normal use. If possible, heat the area (for example, with a space heater) while still ventilating to the outdoors. Avoid blowing the exhaust back indoors or into other nearby residences.
- **Clothes or shoes that did not come in direct contact with liquid mercury should be removed and put into the trash bag** that was left outside the contaminated area at the beginning of the cleanup. Close the trash bag and take it outdoors. Carefully remove the shoes and or clothing from the trash bag and air them out thoroughly outdoors for 24 to 48 hours. After the outdoor

airing, items that are washable can then be laundered.

- **Dispose of contaminated items properly!** Mercury-contaminated items should not be placed in the regular household trash. Contact your town or county officials for information about hazardous waste disposal in your community.

### Mercury Spill Kit Suppliers

Crackle Scientific	800-334-7725
--------------------	--------------

Lab Safety Supply	800-356-0783
-------------------	--------------

Cole-Parmer	800-323-4340
-------------	--------------

### For schools and businesses only:

Fisher Scientific	800-766-7000
-------------------	--------------

Mallinckrodt/Baker	800-582-2537
--------------------	--------------

Sigma Aldrich	800-325-3010
---------------	--------------

VWR Scientific	800-932-5000
----------------	--------------

### For schools only:

Fisher Scientific	800-452-1261
-------------------	--------------

# Package Contents

- 1) One ODOROX® Boss XL3™ Hydroxyl Generator
- 2) One Washable Filter
- 3) One Set of Keys
- 4) One Owners Manual



Note: Air mover not included

# Operating Guidelines

The Boss XL3™ unit is designed for large areas that require strong hydroxyl output to sanitize and deodorize. It can be used in large commercial open spaces and is ideal to treat large areas affected by fire and smoke, flood, nicotine, grey/black water, decomposition, mold, sewage and chemical spills or off-gassing. This unit is designed for use with an existing air mover (air mover is not included).

The table below summarizes the minimum treatment area in the absence of ventilation, and the treatment area range under typical operating conditions: 3 air changes per hour, 90% recirculated air, and 9 foot (2.7 m) ceilings. If the treated space contains a high contaminate or odor load, the effective treatment area will be smaller than the range listed below. These guidelines should be adhered to for optimal performance and safety.

<b>Minimum Area (no circ)</b>	2,006 ft <sup>2</sup> [186 m <sup>2</sup> ]
<b>Treatment Range (ft<sup>2</sup>)</b>	1,700 - 3,250
<b>Treatment Range (m<sup>2</sup>)</b>	158-302





# Operating Instructions

Note: The ODOROX® Boss XL3™ Unit requires an external air mover to function (not supplied with Boss XL3™ Unit). The air mover must be operating on high speed and situated as seen in the picture on page 4 before the Boss XL3™ Unit will function.

## POWER ON

The red “Power On” LED will turn on when the Boss XL3™ Unit is plugged into a proper power source. With the red “Power On” LED turned on, the Boss XL3™ Unit can be powered on by turning the “Generator” switch to the “Low” or “High” position (refer to Note above). The green “Generator On” LED will indicate when the Boss XL3™ Unit has either two or three ODOROX® hydroxyl generating optics functioning.

## POWER OFF

The main power for the Boss XL3™ Unit can be switched off by turning the “Generator” switch to the “Off” position.

## GENERATOR

The Boss XL3™ Unit is equipped with three hydroxyl generating optics. With the “Generator” switch in the “Low” position, two optics will be functioning. With the “Generator” switch in the “High” position, three optics will be functioning.

## HOURLY METER

The Boss XL3™ Unit is equipped with a meter that monitors the hour usage of the unit. This is beneficial for monitoring the life of the optics, length of treatment time, maintenance and cleaning cycles.

# Care Instructions

⚠ Caution: DISCONNECT the unit from an electrical power source before performing any maintenance or cleaning on the unit.

## SYSTEM CASE CLEANING

### EXTERIOR

The exterior of the ODOROX® product can be cleaned with mild dishwashing detergent and a clean cloth, and then rinsed with clean water. DO NOT use any all-purpose cleaners with harsh detergents or abrasives, as these may damage the decals and the exterior finish. Care should also be taken to avoid spraying or otherwise directing detergent or water into or around electrical components.

### INTERIOR

The interior of the ODOROX® product can be cleaned in the same manner as the exterior.

## OPTIC CLEANING

Cleaning of the optics is recommended to maintain peak processing efficiency. Fingerprints, smudges, dirt, dust particles, etc. will interfere with the hydroxyl production and should be avoided.

**Note: Remove the optics from the optic chamber prior to cleaning to avoid any damage to the optics during the cleaning process (refer to the Optic Replacement Instructions and Safety Information for proper removal).**

To clean the optics, use a solution of 10% Isopropyl Alcohol and 90% filtered/distilled water on a clean lint-free cloth and wipe gently. **DO NOT use any type of commercial glass cleaner.** Using another lint-free cloth, gently wipe the optic until completely dry. Allow the optic to dry completely before operating the system.

# Optic Replacement Instructions

⚠ Warning: DISCONNECT the unit from the electrical power source before performing any maintenance or cleaning on the Boss XL3™ Unit.

⚠ Caution: Optics contain Mercury. Read and follow the Safety Information on pages 2 and 3 of this manual when handling the optics in the Boss XL3™ unit.

**STEP 1:** Turn Main Power switch to the “Off” position

**STEP 2:** Unplug power cord from the electrical receptacle

**STEP 3:** Using the supplied key, unlock and remove both end panels

**STEP 4:** Remove optics following these instructions:

**CAUTION!: Use clean powde-free latex gloves and eye protection when handling the optics in this unit**

- With a firm grip on the upper porcelain end of the optic, use your other hand to grip the optic connector
- Gently ‘wiggle’ connector while pulling from the optic base
- Gently pull optic from three lamp supports (**DO NOT put any pressure on the side of the optic without support**)

**STEP 5:** Install new optic following these instructions:

- Remove new optic from packaging and gently insert into the three optic clips
- With a firm grip on the upper porcelain end of the optic, use your other hand to grip the optic connector
- Gently connect the optic connector to the optic

**Note: Optic connector is keyed with the optic base and will connect in one direction only**

- Ensure optic connector and optic base are firmly pressed together

**STEP 6:** Re-install end panels and lock with the supplied key

**STEP 7:** Plug power cord back into the electrical receptacle

**STEP 8:** Test unit for proper operation

# Troubleshooting Guide

Problem	Possible Cause	Solution
<b>Red “Power On” LED will not light up</b>	Boss XL3™ Unit is not plugged into an energized electrical receptacle.	Ensure circuit breaker is “On” and the electrical receptacle has proper power available.
	Red LED has failed.	Contact local distributor for service.
	“Generator” switch is not turned on.	Turn on “Generator” switch to “Low” or “High” position.
	Auxiliary air mover not connected to Boss XL3™ Unit and turned on as shown in manual.	Position Boss XL3™ Unit and auxiliary air mover as shown in manual and turn on air mover.
<b>Green “Generator On” LED will not light up</b>	Auxiliary air mover not turned on high speed.	Turn auxiliary air mover on to high speed.
	Auxiliary air mover not rated for high enough static pressure (low amperage unit).	Try the setup using an alternate auxiliary air mover.
	Negative pressure tubing is kinked or not in the correct position to activate the pressure switch.	Ensure that the negative pressure tubing (clear 1/4 inch) is pulled through into the 7 inch discharge nozzle of the Boss XL3™ Unit and that it is not kinked.
	Green LED has failed.	Contact local distributor for service.
<b>Optic not functioning</b>	Internal component failure.	Contact local distributor for service.
	Rated life of optic has been met.	Contact local distributor for replacement optic service.
	Optic has been damaged.	Contact local distributor for replacement optic service.
<b>Reduced Hydroxyl Production</b>	Internal component failure.	Contact local distributor for service.
	Dirty internal component.	Ensure internal components are cleaned as per the instructions in this manual.
	Rated life of optic/s has been met.	Contact local distributor for replacement optic service.

## Specifications

<b>Dimensions (LxWxD):</b>	20.25" [514.35mm] x 11.12" [282.44mm] x 20.25" [514.35mm]
<b>Weight:</b>	25.00lbs [11.34kg]
<b>Voltage:</b>	<b>Model BXLO3TAA</b> - 120VAC, 60Hz <b>Model BXi03TAA</b> - 210-240VAC, 50/60Hz
<b>Power:</b>	160W (Nominal) / 195W (Max)
<b>Control:</b>	Selector Switch
<b>Meter:</b>	1/10 Quartz Hour Meter
<b>Mobility:</b>	Handle/Rubber Feet
<b>Noise Level:</b>	N/A (refer to air mover specifications)
<b>Optics:</b>	3
<b>Fan:</b>	N/A (refer to air mover specifications)
<b>Certifications:</b>	<b>Model BXLO3TAA</b> - ETL US/Canada <b>Model BXi03TAA</b> - CE

## Replacement Parts

For replacement parts, warranty service, or any questions regarding the operation and maintenance of your ODOROX® product, please contact your local ODOROX® distributor. To find a distributor in your area, please visit:

[www.pyureco.com/contact](http://www.pyureco.com/contact) or [www.odorox.com/contact](http://www.odorox.com/contact)

PYURE Part #	Quantity	Part Description
OPT-XX-078	3	OPTIC, 'B' Hydroxyl U-Optic, Brown
XSA00EW02	3	OPTICS POWER CABLE - Boss/XL3
XSA00EA01	3	Ballast Assembly (BXLO3TAA)
XSA00EA06	3	Ballast Assembly w/Broadband (International) (BXi03TAA)
EPC-IL-021	1	LIGHT MODULE, Protected LED, 110-120VAC, XB4, Green (Model BXLO3TAA)
EPC-IL-596	1	LIGHT MODULE, Protected LED, 195-264VAC, XB4, Green (Model BXi03TAA)
XSA00EA04	1	Hour Meter Assembly
EPC-IL-148	1	LED MODULE, 110-120VAC, RED (BXLO3MA00)
EPC-IL-597	1	LED MODULE, 210-240VAC, RED (BXA03MA00, BXE03MA00)

## Limited Warranty

The PYURE Company, Incorporated warrants that this ODOROX® product (excluding spare parts and consumables) shall be free from defects in workmanship or materials for a period of two (2) years from the delivery thereof to the customer.

PLEASE KEEP THIS PART FOR YOUR RECORDS

Serial #: \_\_\_\_\_

Model #: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Vendor Name: \_\_\_\_\_

**The PYURE Company**

2055 High Ridge Road  
Boynton Beach, FL 33426

(561) 735-3701 | [www.pyureco.com](http://www.pyureco.com)

Complete below and reverse side. Tear along perforation  
and mail to The PYURE Company within 60 days of purchase.

**You may also visit [www.pyureco.com](http://www.pyureco.com) and register your warranty on-line.**

From: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Place  
Stamp  
Here

**The PYURE Company**

2055 High Ridge Road  
Boynton Beach, FL 33426

The PYURE Company (“PYURE”) warrants that the product set forth below will be free from defects in materials and workmanship for the period of two (2) years from the date of original purchase under the following terms and conditions: To obtain service under this warranty, send or deliver this product within the warranty period together with the warranty certificate to any PYURE regional office or PYURE authorized warranty service center. If requested, by PYURE or a PYURE authorized service center, you must present proof of purchase showing date and place of purchase. If upon inspection by PYURE or an PYURE authorized warranty service center, the product is proved to be defective, it will be repaired without charge using, if necessary, new parts or comparable used parts that have been fully reconditioned and returned to you. The warranty period for replacement parts shall extend for a period of six (6) months following the installation of same or for the remaining period of this warranty whichever is longer. This warranty card does not apply in the following cases: (a) damage to product due to mishandling, alteration, failure to follow operation, maintenance or environmental instructions prescribed by applicable instruction manual or shipping damage; (b) damage caused during service performed other than PYURE or an PYURE authorized service center; (c) if the product has had its serial number(s) or other identifying data removed; or (d) damage, defect or unsatisfactory performance caused by the use of equipment not manufactured or distributed by PYURE. IN NO EVENT WILL PYURE BE LIABLE FOR ANY DAMAGE, INCLUDING INCONVENIENCE, LOST PROFITS, OR LOST SAVINGS, OTHER INCIDENTAL DAMAGE STEMMING FROM THE USE OF THE PRODUCT OR OUT OF DEFECTS THEREIN, OR BY BREACH OF THIS EXPRESSED WARRANTY OR ANY IMPLIED WARRANTY WITH THE RESPECT OF THIS PRODUCT, WHETHER ON ACCOUNT OF NEGLIGENCE OR OTHERWISE, EVEN IF PYURE OR AN PYURE AUTHORIZED WARRANTY SERVICE CENTER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states or provinces do not allow limitations on how long an implied warranty lasts or limitations of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province.

**Purchaser’s Name:** \_\_\_\_\_

**Address:** \_\_\_\_\_

\_\_\_\_\_

**City:** \_\_\_\_\_ **State/Prov:** \_\_\_\_\_

**ZIP/Postal Code:** \_\_\_\_\_

**Purchaser’s Type of Business:** \_\_\_\_\_

**Primary Use for Machine:** \_\_\_\_\_

\_\_\_\_\_

**Model Type:** \_\_\_\_\_ **Serial #:** \_\_\_\_\_

**Vendor’s Name:** \_\_\_\_\_

**Vendor’s Address:** \_\_\_\_\_

\_\_\_\_\_

# Limited Use End-User License Agreement

This End-User License Agreement (EULA) is a legal agreement between you (either an individual or a single entity) and the mentioned owner (The PYURE Company) of any computer software which may include associated firmware, media, printed materials, and “online” or electronic documentation (“Licensed PYURE Software”).

By installing, copying, or otherwise using the Licensed PYURE Software, you agree to be bounded by the terms of this EULA. If you do not agree to the terms of this EULA, do not install or use the Licensed PYURE Software in the Odorox® product.

Licensed PYURE Software.

The Licensed PYURE Software is protected by U.S. and international copyright, patent, trade secret laws and well as other international intellectual property laws and treaties. Upon your acceptance of this EULA, The PYURE Company grants to you a nonexclusive, revocable license to use the Licensed PYURE Software, provided that you agree to the following:

## 1. Grant of License.

The Licensed PYURE Software is licensed, not sold. You own a copy of any media or hardware on which the Licensed PYURE Software is shipped, but not a copy of the Licensed PYURE Software itself. The PYURE Company retains all title, copyrights, and other intellectual property rights in the Licensed PYURE Software and any copies thereof. You may use a copy of the Licensed PYURE Software with any Odorox® product for which you have accepted the terms of this EULA.

## 2. Restrictions.

You must maintain all notices including copyrights on all copies of the Licensed PYURE Software. You may not modify, adapt, translate, reverse engineer, decompile, disassemble, or otherwise attempt to learn the source code of the Licensed PYURE Software, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

## 3. Termination.

Your rights under this EULA terminate upon your termination of this EULA, or without prejudice to any other rights, The PYURE Company may terminate this EULA if you fail to comply with its terms and conditions. In such event, you must destroy all copies of the Licensed PYURE Software.

## 4. No Software Warranty Independent from Other Warranties.

The Licensed PYURE Software is being delivered to you “AS IS” and The PYURE Company makes no warranty as to its use or performance, other than any the “Limited Warranty” on the Odorox® product described above.

## 5. LIMITATION OF LIABILITY.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE PYURE COMPANY OR ITS SUPPLIERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES



OR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, LOSS OF SAVINGS, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE LICENSED PYURE SOFTWARE PRODUCT, OR FOR PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES, EVEN IF THE PYURE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

THE ENTIRE LIABILITY OF THE PYURE COMPANY AND YOUR EXCLUSIVE REMEDY UNDER THIS EULA IS, AT THE OPTION OF THE PYURE COMPANY, CORRECTING OR WORKING AROUND ERRORS, REPLACING THE MEDIA, OR REFUNDING THE PURCHASE PRICE. IN NO EVENT SHALL THE PYURE COMPANY'S ENTIRE LIABILITY UNDER THIS EULA EXCEED THE PURCHASE PRICE (EVEN IF THE LICENSED PYURE SOFTWARE PRODUCT IS DOWNLOADED WITH OTHER THIRD PARTY SOFTWARE FREE OF CHARGE) OF THE LICENSED PYURE SOFTWARE PRODUCT.

### 6. Miscellaneous.

This EULA is governed by the laws of the State of Florida, U.S.A., and jurisdiction for any action based on the Licensed PYURE Software shall lie in a court located in Palm Beach County Florida. If any part of this EULA is found void and unenforceable, it will not affect the validity of the balance of the EULA, which shall remain valid and enforceable according to its terms. Should you have any questions concerning this EULA, or if you desire to contact The PYURE Company for any reason, please visit: [www.pyureco.com/contact](http://www.pyureco.com/contact).



## Need Support?

Contact our support team

| +1 (877) 735-3701  
| [sales@pyureco.com](mailto:sales@pyureco.com)

Copyright 2020, The PYURE Company

ODOROX® and Boss XL3™ Powered by PYURE Technology™ are trademarks of The PYURE Company, Boynton Beach, FL 33426 USA